

## W106 SLIDER HANDLE/LOCK REPLACEMENT INSTRUCTIONS

### 1. TOOLS

- Rubber Hammer
- Felt Pen
- Robertson Screw Driver (#2)
- Flat Head Screw Driver
- Silicone (fast curing)

### 2. W106 INSTALLED HANDLE



### 3. REMOVAL PROCEDURE

- Open sliding panel fully. Pull out top track material with finger or hook shaped tool.
- Lift up on sliding panel and pull bottom towards you out of frame.
- Remove screws which attach T-bar to vent extrusion.
- Remove vinyl from T-Bar and pull T-Bar from vent.
- Carefully tap vent material with rubber hammer to remove vent from glass.
- Pull vent rubber gasket away from glass.



- g. Trace around old handle with felt pen.
- h. Remove old handle.
- i. Remove film from two-sided tape and place a small bead of silicone on new handle beside tape. - Attach new handle.
- j. Replace gasket material around glass.
- k. Put vent back onto glass panel. - Check to make sure it is parallel.
- l. Attach T-Bar to vent with screws and replace vinyl.
- m. Put top of vent into window frame.
- n. Push bottom in and down to bottom track.
- o. Replace top track by snapping in the end behind closed window vent and sliding in towards the front of the window.

#### 4. MAINTENANCE AND REPLACEMENT PARTS

Ensure that you carefully review and check your W106 handle assembly. And while the window is out for handle repair, check that your gaskets, t-bar and track are all in good working order. This is the time to replace key components. See parts list for maintenance and repair lists.

All parts are available online at [www.theamtstore.com](http://www.theamtstore.com).

#### 5. PARTS LIST

##### W106 Handle Parts

Description	Part Number	Notes / Checked
Handle Lock Set (with Keeper), Nylon, W106 series, Black	HW-RS1000	
Lock Keeper, Nylon, W106 series, Black	HW-LSDIA007A	
Lock Hook, Metal (Zinc), W106S series	HW-LSDIA009	

##### W106 Window Gasket and Track Maintenance & Replacement

Description	Part Number	Notes / Checked
106 PLUG	AD-VY2170BM	
106 TRACK	AD-VY1802	
T BAR FLAP 106	AD-VY1801	
Grey Weather stripping (no fin) – For XVent	AD-WS187_8335D5	
Grey Weather stripping w/fin (Tbar)	AD-WS270_7532	
Fulcrum Glazing (default when WD has 6mm - 10mm GL)	AD-VY2572	
Fulcrum Glazing (default when WD has 12mm GL)	AD-VY2572A	